

Recommended accessories

	<i>Description</i>	<i>Model</i>
	<i>Canon EOS Rebel T6i (without lens)</i>	<i>0591C004</i>
	<i>Lens Sigma 10-20MM F3.5 EX (Canon)</i>	<i>EX1020HC</i>
	<i>Remote switch Canon RS-60E</i>	<i>082966581359</i>
	<i>Optex 77MM lens protect</i>	<i>059497061681</i>
	<i>Memory card SDHC 4G</i>	